

PolySatin Shutters

Measuring for Divider Rails

Divider rails are easy to measure follow the steps below:

- Always measure from the bottom floor or sill to the middle of where the Divider Rail is to be position
- If measuring for more than one Divider Rail, go back to the floor or sill and measure up to the second Divider Rail position
- A Divider rails give the panel extra stability but also allow for individual louvre control above and below the divider rail



Example: Window Height is 2000mm with one Divider Rail required
Divider Rail measurement is 750mm

NOTE:

- **One divider rail is required for panels over 1500mm in height**
- **Two divider rails are required for panels over 2700 in height with a maximum of 1500 between any two rails.**