

PolySatin Shutters

Measuring for T-Posts

T-Posts are easy to measure; follow the steps below:

- Always measure from the left inside reveal (where the frame is to sit) to the centre of the first T Post position.
- If measuring for more than one T-Post, go back to the left inside reveal and then measure to the next T Post position and so on.



Example: Window Reveal width is 1500 with two T-Posts.
1st T-Post at 500mm
2nd T-Post at 1000mm