

Alpha External Screen Awnings

Cable Hole Location

A 12mm hole is required to be drilled through the back of the extrusion of the headbox in order for the cable to be run from the inside to the outside where an electrician will connect to the mains.

- There are two suggested hole locations however these will be determined once location of where the headbox will be installed has been located.
- The installer needs to ensure that when drilling the 12mm hole, that it is away from the main installation bracket (approx. 70mm towards the center of the tube)
- Option 3 is used when mounting where the cable is preferred to come out the side of the headbox instead of the back. The top front corner is suggested for this method as this has less issue with interfering with the tube/fabric.

With Alpha Automated Awnings, the exact location of the hole can be left at the discretion of the installer as the cable can come out at any point that will work for that particular installation.

The biggest thing to note when completing this step is to ensure the cable is away from the end brackets and not rubbing against the fabric.

NB: A gromet must be used to ensure the cable does not rub against a metal edge.

