

# Timber Shutters

## Measuring for Divider Rails

Divider rails are easy to measure follow the steps below:

- Always measure from the bottom floor or sill to the middle of where the Divider Rail is to be position
- If measuring for more than one Divider Rail, go back to the floor or sill and measure up to the second Divider Rail position
- A Divider rails give the panel extra stability but also allow for individual louvre control above and below the divider rail



Example: Window Height is 2000mm with one Divider Rail required  
Divider Rail measurement is 750mm

### NOTE:

- One divider rail is required for panels over 1800mm in height
- Two divider rails are required for panels over 2700 in height

If the midrail location needs to be 100% at the measurement, note  
“Critical Midrail” in the Factory Requirements