

Irismo Wirefree

Adding or Deleting Somfy Control Points

Adding or Deleting Somfy Control Points

1. Find an RTS remote control programmed in the motor.
2. Press & hold the RTS programmed remote control (A) PROG button or the receiver prog button until the motorised product moves, the motor is in programming mode.
3. Quickly press the RTS remote control (B) PROG button to add or delete, the motorised product moves & the RTS remote control (B) is programmed or deleted from the motor.