

# Q-Motion

## Battery Replacement

Over time your Q-Motion blind may start to roll much slower when moving both up and down. This may indicate it is time to change the batteries. When batteries require replacement, it is possible to replace the batteries without removing the blind from the brackets.

To activate the battery replacement process

1. Press down button on the remote to send the blind to the fully down position
2. When the blind is fully down, pull down gently on the fabric to expose the battery opening on the aluminium tube
3. Release the fabric/blind and the blind will return to the 75% closed position
4. Pull down gently on the fabric to expose the aluminium tube and battery opening a second time, and the blind will remain in that position (without retracting)
5. Replace the batteries by sliding them along and out through the opening
6. Replace all batteries with similar D Cell Alkaline long-life batteries, ensure that the positive (+) terminal on the battery is facing the opening
7. Once complete, press the UP button on the remote and the blind will resume operation

