


# Sonesse 30 WF Li-ion RTS

## \*Disabling/Activating for Storage & Shipment

**Note:** \*The motor must be completely programmed with a remote.  
Disabling the radio receiver saves battery life during shipment or for extended periods of non-use.

### 1. ENTER PROGRAMING MODE

1. Hold the program button on the motor until the motor jogs  
The green LED on the motor will begin flashing
  - To activate radio receiver, continue to Step 2
  - To deactivate radio receiver, move to Step 3



### 2. ACTIVATE RADIO RECEIVER

Press the program button on the motor until it jogs




### 3. DEACTIVATE RADIO RECEIVER

Hold The UP, MY & DOWN buttons on the remote. The motor will jog



## FLOWCHART FOR DEACTIVATING/ACTIVATING MOTOR FOR STORAGE & SHIPMENT



\*The motor must be completely programmed with a remote.

Disabling the radio receiver saves battery life during shipment or for long periods of non use.