


Eolis & Soliris Wind Sensor RTS Wiring Diagram



For programming and resetting purposes, we strongly recommend a means to switch on/off one motor at a time.