

PowerView Hub


How to use Remote Connect Feature

Remote Connect is required to be setup if your customer wishes to access the assigned scenes from a different Wi-fi network or via their smartphone on a 3G, 4G or 5G network.


Remote connect will not allow you to control your shades individually but will allow you to control any scenes that have been setup.

How to use Remote Connect Feature


- The HUB must be connected to an Internet Network
 - Remote Connect will work only if there is an internet connection on both sides: At home with the HUB and also on the mobile device when outside of the home
1. When the PowerView app is opened, you will be presented with a screen that says "connect to Hub", tap this button.




2. Outside of the home network, the only option available for connecting to a HUB is via Remote Connect, tap 'connect'



3. The app will show you a confirmation message



- When you click OK, the app will display you all the scenes previously created. The dashboard and rooms options will be greyed out while using Remote Connect



- You can now operate your scenes

