

PowerView Hub

Hub LED Light Behaviour

IMPORTANT

The Powerview Hub LED behaviour will change after initial start-up.
Please see the chart below for updated Hub LED behaviour.

HUB STATUS	ON INTIAL START-UP	AFTER FIRMWARE UPDATE
Power On	Solid Aqua	Solid Aqua
Bootup	Blinking Amber	Blinking Aqua
Downloading & Applying Firmware Update	Solid Amber	Solid Amber
Ready to Connect to WiFi Network	Solid Amber	Solid Magenta
Ready to Join a Powerview Network	Blinking Amber	Blinking Amber
Connected to a Powerview Network, Normal Operation	Solid Blue	Solid Blue
Transmitting a Powerview Signal	Flashing Blue	Flashing Blue
Connected to a Powerview Network, Normal Operation (Secondary Hub)	Solid Green	Solid Green
Transmitting a Powerview signal (Secondary Hub)	Flashing Green	Flashing Green
No IP Address		Solid Red

