


# LT 50 Mariner WT with Inis Uno Wall Switch Wiring Diagram



ACTIVE  
NEUTRAL  
EARTH

240 V 50Hz

Note:  
Directions can be reversed by swapping the two active wires from the motor to the appropriate terminal on the Inis Uno. Directions are determined by the motor's position & the direction of roll.