

# Irismo Wirefree

## Low Battery Charge Indicator

### **Low Batter Charge Indicator**

1. Motor will emit one audible "beep" ( one "beep" before motor start to run and another "beep" after the operation )follow operation of Drapery motor.

### **Charge battery**

2. Motor will emit one "beep" and LED red fast blink when no battery.

### **Charge the battery**