

Glydea WT

Modifying the Motor Direction


***Note:** Requires a DCT setting tool or a 3 button normally open Dry Contact switch with Open (Up), Top & Close (Down) buttons.

Somfy Tip: The WT Motor Direction can also be changed by swapping the directional (Brown & Black) wires.


1. Ensure the Motor is Installed on a Curtain Track



2. Change Motor Direction




Maintain power on the motor in either direction and wait until the curtain stops.




Press and hold the Open (up), Stop and Close (down) buttons simultaneously on the DCT setting tool or a dry contact switch until the motor jogs once.

3. Save New Motor Direction



Press and hold the Stop button until the motor jogs once. The motor direction has been changed.

Flowchart for Modifying the Motor Direction



Note: Requires a DCT setting tool or a 3 button normally open Dry Contact switch with Open(UP), Stop & Close(DOWN) buttons