


Altus 28 WF Li-ion RTS

Modifying the Motor Rotation Direction

Note: Before changing the motor direction, the motor must be completely programmed


Move the Motor Away to the centre




Enter Programming Mode



Reverse Direction of the Motor



Flowchart for Modifying the Motor Rotation Direction



Before changing the motor rotation direction, the motor must be completely programmed with a remote