

Irismo Wirefree

Modifying the Motor Rotation Direction

Modifying the Motor Rotation Direction

Move the motorised product away from the end limits

1. Press the Open and Close buttons of the RTS remote control simultaneously until the motorised product moves.

The LED is green or green blink

2. Press the my button until the motorised product moves to reverse the rotation direction.