

Glydea WT

Modifying the Motor Speed


1. Enter Programming Mode



Maintain power on the motor in either direction and wait until the curtain stops. Press and hold the Mode button until a Green LED appears.



Briefly press the Mode button 3 times.



The LED will begin flashing Red and Green, the motor will open and close continuously.



Toggle the speed setting by briefly pressing the Set button.



Briefly press the Mode button to confirm speed. A Green LED will appear.



Press and hold the Mode button until the Green LED turns off.

Flowchart for Modifying the Motor Speed

Note: A small paper clip is required for pressing the Mode & Set buttons,

