

PowerView Scene Controller Programming

Configuring the Scene Controller

1. Check to be sure your PowerView Hub is powered up, connected to a wireless router, and the light on the Hub is a solid blue.
2. For INITIAL CONFIGURATION ONLY: press any button on the Scene Controller to activate controller. Screen should read: "Join Hub?"
3. Open the PowerView App on your mobile device.
4. Select the "Add New Controller" menu option in the PowerView App (under Hub Settings).
5. Follow the instructions on the App screen to configure the Scene Controller.

The Scene Controller is now joined to the PowerView Hub. You may now use the PowerView App to configure which Scene names are displayed on the Scene Controller.

For additional Scene Controllers follow the instructions listed above.

Updating Scene Name List in the Scene Controller

1. Press and hold the "select" button for 4 seconds until the buttons begin to flash. This puts the Scene Controller into Program mode.
2. Use the arrow buttons (< and >) to navigate the programming menu options:
 - a. "Update Scenes?"-Scene Controller communicates with the PowerView Hub to get updated Scene name information.
 - b. "Forget This Controller?"-clears all programming from the Scene Controller.
 - c. "Exit Menu?"-exits programming mode.
3. Use the "select" button to activate a menu option.



Basic Operation

1. To wake the Scene Controller, press any button. The last scene activated is displayed on the screen.
2. To activate one of your FAVOURITE Scenes, press HEART or DOUBLE HEART button. Use the App to configure FAVOURITE Scenes.
3. To activate other Scenes, use the arrow buttons (< and >) to scroll through the Scene name list.
4. Press "select" to activate the Scene displayed on the screen.

NOTE: The Scene name will flash until the command has been confirmed by the PowerView hub

