

Q-Motion Gen 3

Setting the Bottom Limit

Use these programming instructions when the bottom limit of the blind needs to be changed

1. Select the channel on the remote the blind is paired to

2. **Press and release the DOWN button**
(Blind will move to set bottom limit)

3. **Press and hold the DOWN button** until the blind jogs

4. **Pull down on the bottom bar** more than 250mm
(The blind will jog in response)

5. **Adjust blinds bottom limit manually**
(Pull on the bottom bar to move the blind to required bottom limit. If the bottom bar drops too low, manually roll the fabric back up until the bottom limit position is reached)

6. Once you are happy with the new bottom limit, **press and hold the DOWN button** until the blind jogs

7. New bottom limit has now been set and saved