

Q-Motion Gen 3 Special Learn Command

Use these programming instructions if the blind times-out without being paired to a remote or if adding a second remote or channel to the shade

1. Manually roll shade up by hand to start from the top limit

2. Using a paper clip, **press the program button** on the back of the remote control (The channel LED's will scroll back and forth when in programming mode)

3. **Press and hold the channel button** until the blind moves.
The blind will travel to the 25% position

4. **Pull the bottom bar more than 250mm**
(Blind will jog in response)

5. Select desired channel on remote control

6. Using a paper clip, **press the program button** on the back of the remote control (The channel LED's will scroll back and forth when in programming mode)

6. **Press and release the UP button.**
(Blind will jog, move to the top limit and then jog again)