

Roll Up 28 RTS & WireFree Roll Up RTS

Erasing the memory of the motor




1


Resetting




Press the program button for 12 seconds



2 sec = jiggle or LED illuminates



7 sec = jiggle or LED blinks




12 sec = jiggle or LED turns off.
The motor has been reset



All remotes including remote used to finalise will be deleted along with the limit programming and any sensors that have been programmed.

Roll Up 28 RTS & WireFree Roll Up RTS

Erasing the memory of the motor



IMPORTANT NOTE:

This procedure is useful if the existing limits cannot be accessed for adjustment or if a clean start is required.