
Programming



Motor overview

The motor head of the WireFree Roll Up incorporates a program button and a port for the battery pack cable.

The program button is used to reset the motor to factory mode or to pair additional remote controllers.



2 — Power to the motor

Reloadable Battery Wand





Connect battery pack – Continue to step 3

3 Control the motor and check the correct direction of rotation



Press and hold simultaneously

the Up and Down button.

The blind should jiggle.








Press the Down button.
Does the blind move down?


YES – The blind moves down while pressing the down button – Go to step 5.

NO – The blind moves up while pressing the down button – Continue to step 4.

Programming








Programming








Press and hold the **my** and Up button until the blind starts to move up.




The blind will automatically stop at the up position.



Press and hold the **my** button until the blind jiggles to confirm the limit settings.

7 Programming the RTS control to the motor

Press the program button on the RTS control until the product jiggles.



Smoove RTS



Situo RTS



jiggle = control recorded






Use only 1 RTS control throughout the commissioning procedure.



Programming





Programming



