

Q-Motion - Gen 2

Remove Battery Method

1. Gently pull down on the bottom bar to expose the battery cut-out on the blind tube

2. Place a hand firmly on the blind tube to stop the blind automatically retracting

3. The blind will hesitate, and then stall, allowing you to gain access to the battery insert

4. Remove the battery cover (If installed)

5. Remove one battery and reinsert the battery

6. The blind is now in pairing mode for 1 minute

7. Press and HOLD the UP button on the remote control for 8 seconds, or if using the multichannel remote, select the required channel number first

8. The blind will retract to signal the remote control is paired