

Q-Motion Gen 3

Pair the Remote Control in Transport Mode

Completing these programming instructions may be a requirement when the blind arrives for initial installation

1. Select the channel on the remote the blind is paired to

2. **Pull DOWN on the bottom bar** more than 250mm.
The blind will jog in response

3. Using a paper clip, **press the program button** on the back of the remote control (The channel LED's will scroll back and forth when in programming mode)

4. **Press and release the Up button** on the remote. The blind will jog, move to the upper limit and then jog again

5a. If the blind jogged, pairing is complete.

5b. If the blind didn't jog, complete the below steps.

6. Remove the battery from the tube for a minimum of 30 seconds and then place back in

7. Start the pairing process again but following instructions named "**Special Learn Command**"