

Sonesse 30 WF Li-ion RTS Motor Side Understanding

Motor defaults to the right hand side. This is done for ease of access to the charging port when the blind is installed.

Top Fix example



If you choose to have the motor on the left, the charger port will be difficult to access so you will need to rotate the adapter at the end of the motor head. For this change, you will require a T20 star Head bit to unscrew screws from plate.



Step 1 - Remove the adapter plate



Step 2 - Turn the adapter 90 degrees and screw back into place



Step 3 - Alternatively, you may wish to turn the motor in the bracket from straight up and down to the next slot. Note: This will not stop the motor from working efficiently.

