### Roll Up 28 RTS & WireFree Roll Up RTS


## Adjusting RTS motor limit positions





Press the Down button and send the product to the lower limit position.





Press and hold the Up and Down buttons until the product jiggles.








Adjust to the correct position using either the Up or Down button.











Press and hold the my button until the product jiggles.







#### Adjusting the Upper limit position


Press the Up button and send the product to the upper limit position.





Press and hold the Up and Down buttons until the product jiggles.







Adjust to the correct position using either the Up or Down button.











Press and hold the my button until the product jiggles.





New limit position set



## Roll Up 28 RTS & WireFree Roll Up RTS

# Adjusting RTS motor limit positions



