## PowerView Hub Setting up Remote Connect Feature

Remote Connect is required to be setup if your customer wishes to access the assigned scenes from a different Wi-fi network or via their smartphone on a 3G, 4G or 5G network.


Remote connect will not allow you to control your shades individually but will allow you to control any scenes that have been setup.

## Setting up Remote Connect Feature


- To activate and set up the Remote Connect feature, the HUB and the mobile device must be connected to the same Wi-Fi network.
- The Remote Connect feature allows you to operate previous scenes created on the PowerView app ONLY, you cannot individually control blinds via Remote Connect.
- If the PowerView app is to be connected with a third party app such as IFTTT,
  Google Home, Alexa, etc., the same e-mail address used to create the
  PowerView account will need to be used to create other accounts to link the
  information.
- 1. Open the PowerView app on the device




Tap the drop down menu on the top left hand corner of the screen



3. Tap on "PowerView Account" from the selection pane at the top.




4. On the screen, tap the window "Create Account"






5. Fill in all the fields on the "Create Account" screen. You must provide an e-mail address. Make sure you have easy access to this e-mail address to confirm your registration.




After you submit your information, you will receive an e-mail to confirm your PowerView account. Click the link in the email to confirm account.

6. Sign into PowerView using the same e-mail address from which you confirmed your PowerView account. From the menu on the left hand side of the screen, select 'PowerView account' then 'Have an account? Sign In'






7. Once you sign in, the app will ask you to register the HUB



8. Wait until there is a confirmation window



9. To activate the Remote Connect feature, tap the button on the right

